


P2P = CLIENT to CLIENT

Send a message to another Client using Winlink Express [P2P]
Their Winlink P2P session needs to be open and online



PACKET CONNECTING THROUGH A K-NET NODE USING A NODE SCRIPT

WINLINK = CLIENT TO SERVER

Send an email message to
[RMS Packet/Trimode - Server] for pick up



PACKET CONNECTING THROUGH A K-NET NODE USING A NODE SCRIPT